

RF Cable & connector

SMA(M)	SMA(SJ)	SMA(SBJ)	SMA90(M)	SMA90-J-SMT	SMA-J-SMT	SMA90-RJ-SMT	SMA-EDGE-SMT
							
SMB(SP)	SMB(SBJ)	SMB90(SP)	SMB-J-SMT	SMB90-J-SMT	SMB90(SJ)	SMB-EDGE-SMT	SMB(SJ)
							
SMC(SP)	SMC90(SP)	SMC(SBJ)	SMC(SJ)	SMC-J-SMT	1.0/2.3-F	1.0/2.3-M	1.0/2.3-SMT
							
MCX(M)	MCX90(M)	MCX(J)	MCX90(J)	MCX(SBJ)	MCX90-J-SMT	MCX-J-SMD	MCX-M-SMT
							
MMCX(M)	MMCX90(M)	MMCX(J)	MMCX-J-SMT	MMCX(SBJ)	MMCX-J-SMT	MMCX90-J-SMT	MMCX90(M)
							
BNC(M)	BNC90(M)	BNC(SBJ)	BNC90-J-SMT	BNC-J-SMT	BNC(SJ)	SSMB(SJ)	SSMB(SP)
							
TNC(M)	TNC(J)	TNC(SBJ)	TNC(SBJ-1)	TNC90(M)	TNC90-J-SMT	MCX-SWITCH	MMCX-SWITCH
							
FME(SP)	FME(SJ)	FME(SBJ)	FAKRA-C	FAKRA-D	FAKRA-E	FAKRA-A	FAKRA-F
							
N(M)	N(SBJ)	N(J)	N90(M)	FAKRA-K	FAKRA-SMT	FAKRA-SMT	N
							
UHF(M)	UHF(J)	MINI UHF(M)	MINI UHF(J)	CRC9-90	CRC9-180	MC CARD90(M)	MMCX-PCB
							

